




Apollo Linear Actuator

Part Diagrams

816 Actuator



This drawing is a representation and should be used for parts reference only.

Apollo Linear Actuator

Part Diagrams




816 Actuator

Part Name	Part Number	816 Actuator
Bearing Kit	A2087	all
Bracket, Gate Attach, Kit	10015290	all
Bracket, Pivot, Bolt-On	446	all
Bracket, Pivot, Kit, Single & Dual	10055490	all
Bushing, Limit Plate	A2052	all
Cover Tube, Seal Housing Kit	A2024K	all
Extension Tube	A2027	all
Gear Nut, AC	A2006	all
Gear, Spur	A2017	all
Housing, Rear, Kit	A2012	all
Housing, Rear, w/Bushings	A2012K	all
Limit Block w/Magnet	A2002	all
Limit Block, Plastic, No Switch	A2003P	all
Limit Bolt, Proximity	A2005	all
Limit Cap and Seal Kit	A2010	all
Limit Screw	A2019	all
Main Screw	A2018	all
Main Screw Kit	A2086	all
Motor and Pinion Gear	A2014	all
Proximity Switch	A2004	all
Sensor, Smart	A2072	all
Strain Relief	A2029	all

MB1050 with Control Board

Part Name	Part Number	MB1050
Board, Control, 1050	1050US	1551
Box, Control, MB1050	O-MB1050	1551
Receiver, OXI, Multi Channel	OXIBD/A	1551






Apollo Linear Actuator

Part Diagrams

CBOX with Control Board



This drawing is a representation and should be used for parts reference only.

Part Name	Part Number	CBOX
Board, Control, 636	636US	1500
Board, Control, 936	936US	1550
Board, Control, 1050	1050US	1551
Box, Control, CBOX, No Control Board	11111B	all
Key Switch, Single Pole	1115	all
Lid, 11111B, CBOX	10016215	all, 11111B, CBOX
Receiver, OXI, Multi Channel	OXIBD/A	CBOX936, CBOX1050
Switch, Push Button, Control Box	1119	all
Tab, Replacement	10020915	all, 11111B, 11111C, CBOX