


ACCESS THE INSTALLER PROGRAM MODE AND CONFIGURE EACH OPERATOR AS EITHER A MASTER OR A SLAVE.



NOTE: USE ONLY 18-20GA TWISTED & SHIELDED TRIPLE WIRE.



HySecurity Inc. 6623 South 228th St. Kent Wa. 98032-1876

PROPRIETARY INFORMATION OF HY-SECURITY GATE INC. This document and the information contained herein, are the confidential, proprietary, and trade secret information of Hy-Security Gate Inc. ("Hy-Security") Any party receiving, accepting or retaining this document and any information contained therein solely as may be required to manufacture products or components for Hy-Security and will not provide this document, any information therein to any other party, or use it for any other purpose without the express prior written consent of Hy-Security.

DESCRIPTION	"MASTER / SLAVE" DUAL GATE
-------------	-------------------------------

ECN NO: D0013	REV	CHANGE DESCRIPTION	REV BY	REV DATE	PART NO:	SHEET 1 OF 1
------------------	-----	--------------------	--------	----------	----------	--------------